





























## CC121 compatibility chart

Software Version	Support	Notes
		Quick Control
Nuendo 7		
Nuendo 6.5		
Nuendo 6.0		
Nuendo 5.5		
Nuendo 5.0 – 5.1.1		
Cubase Pro 8.0, Cubase Artist 8.0		
Cubase 7.5, Cubase Artist 7.5		
Cubase 7.0, Cubase Artist 7.0		
Cubase 6.5, Cubase Artist 6.5		
Cubase 6.0, Cubase Artist 6.0		
Cubase 5.5, Cubase Studio 5.5		
Cubase 5.1.1, Cubase Studio 5.1.1		
Cubase Elements 8.0, Cubase AI 8.0		Not available
Cubase Elements 7.0, Cubase AI 7.0		Not available
Cubase Elements 6.0, Cubase AI 6.0		Not available
Cubase Essential 5.1.1, Cubase AI 5.1.1		Not available



Full support



Limited support